

ACTUATOR

Specifications						Motor data					
驅動器型號	平台規格	動作時間	最大扭力	手動裝置	防水等級	馬達轉速	消耗電流				淨重
Actuator type	Mounting pad (ISO)	Operation time (SEC/90°)	Max. Torque (N-M)	Manual Part	Weatherproof	Speed rpm	Absorbed current amp (50/60Hz)				N.W. (Kg)
							AC110V	AC220V	AC24V	DC24V	
S07	NO	60	10	✓	IP54	2.5	70mA	30mA		50mA	0.8
S10	F04	15	6.8	✕	IP65	4	0.05A	0.03A	0.22A	0.05A	0.9
		25	8			3					
		35	10			2					
S25	F04/F06	7	18	✕	IP66	300	0.3A	0.1A	0.8A	0.25A	1.7
	F05/F07	30	30								
S37	F05/F07	7	60	✓	IP66	3500	0.22A	0.1A		0.32A	2.7
		75	80								
S150	F07/F10	8	150	✓ Hand-wheel	IP66	1500	0.6A	0.3A			5.8
S152		80	250				1.2A	0.6A			
S200	F10/F12	10	300	✓ Hand-wheel	IP66	1200	4.14A	1.38A			18.5
S202		80	500								

SAFETY INSTRUCTIONS

- 非防爆型, 請勿裝設於可能發生氣爆之區域
Non anti-explosion type. Don't assemble it at possible . Air-explosive area.
- 設置時請勿倒立或傾斜於水平線下
Don't make it upside down or declin it below Water horizontal level in assembling.
- 入線口請以纜線接頭固定, 可避免異物侵入
Fix the line-in slot with cable joint to avoid Odds entering.
- 並聯時,請於啟/閉接點作聯鎖電路
In paralleling combination, make a co-lock circuit at on/off joint.
- 周圍溫度過低時,請加裝電阻器以防止結露現象
Assemble a resistor to avoid dewing ie The peripheral temperature is too low.
- 安裝時請先確定供給電壓是否相符
Make sure the supply voltage is correct Before assembling.
- 配線上有疑問請優先會知供應商,確定後再送電
Please notice the supplier when you have Any doubt in wiring. When everything is Confirmed, the power then can be conveyed.

⊘ 嚴重禁止 Prohibition

同一導電線(源)並聯二台以上使用。
Parallel two sets or more in same circuit .
(Power source)

○ 二台並聯應用方式

Applied method of parallel two sets

二台以上並聯時,應利用繼電器給予獨立控制電源作間接驅動。

When parallel two sets or more, must make use of relay and indirect drive by independent controlled power source.